

KOALA







L I V I N G


Assembly Instruction

Product Name: Aspen Rounded Corners Console Table - Matte Black Legs


Product Id: 129887

Hardware List

- | | | | |
|---|---|---------------------------|-------|
| A |  | Allen Key
5mm | 1 pc |
| B |  | Allen Bolt
M6x16mm | 3 pcs |
| C |  | Silicone Pad
Ø20x3mm | 8 pcs |
| D |  | Washer
4mm | 1 pc |
| E |  | Washer
M8x45mm | 8 pcs |
| F |  | Anti-Slip
Bumper
Ø6 | 4 pcs |




Part List




Note

1. Assemble the item on a soft, well-lit surface like cardboard or carpet.
2. For safety and efficiency, it's best to have two or more people assist with assembly to handle heavy parts safely and collaborate effectively.
3. Keep all packaging materials intact until assembly is complete.
4. Before assembling the item, carefully read all provided instructions.
5. Handle tools with care during assembly to prevent injuries.


1




2




3




4




5




5



6



7



⚠ Warning

- ALWAYS secure this furniture with an anchor device
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves
- ALWAYS secure your television with an anchor device

