

# KOALA





## L I V I N G


### Assembly Instruction

Product Name: Beckham Cream Console Table


Product Id: 127907

#### Hardware List


- |   |   |                           |       |
|---|---|---------------------------|-------|
| A |    | Allen Key<br>5mm          | 1 pc  |
| B |   | Allen Bolt<br>5/16\"*50mm | 8 pcs |
| C |  | Spring Washer<br>Ø19mm    | 8 pcs |
| D |  | Washer<br>Ø13mm           | 8 pcs |




#### Part List




Top  
1 pc



Leg A  
1 pc




Leg B  
1 pc




## Note

1. Assemble the item on a soft, well-lit surface like cardboard or carpet.
2. For safety and efficiency, it's best to have two or more people assist with assembly to handle heavy parts safely and collaborate effectively.
3. Keep all packaging materials intact until assembly is complete.
4. Before assembling the item, carefully read all provided instructions.
5. Handle tools with care during assembly to prevent injuries.


1




2



3



4



### Warning

- ALWAYS secure this furniture with an anchor device
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves
- ALWAYS secure your television with an anchor device

